

YUKON

DIRECT - INTEGRAL DRIVER

Standard Installation



Flammable



Warning



High Voltage



Hot Surface

TOOLS NEEDED:



5/32" and 5/64" Allen Wrench



Waterproof Wire Connectors



1/4" Drill Bit (Hand Held Drill)

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS IMPORTANT SAFETY INSTRUCTIONS

Lighted fixture is HOT!

WARNING - To reduce the risk of FIRE OR INJURY TO PERSONS:

Turn off/unplug and allow to cool before replacing lamp/LED. Fixture gets HOT quickly! Contact only switch/plug when turning on. Do not touch hot lens, guard, or enclosure. Keep fixture away from materials that may burn. Do not operate the luminaire fitting with a missing or damaged shield. Do not touch the source at any time. Use a soft cloth or gloves. Oil from skin may cause damage.

SAVE THESE INSTRUCTIONS


IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS

- Product must be installed by a qualified person in a manner consistent with its intended use and in compliance with the National Electrical Code, Canadian Electrical Code, and all Local and Provincial Codes.
- Follow product label information and instructions.
- Qualified Personnel with appropriate personal protective equipment must perform all servicing of this product.
- Before wiring to power supply and during servicing, turn off and lock out power at fuse or circuit breaker before service.
- The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. The use of damaged components may cause an unsafe condition and void product warranty.
- Do not block light emanating from product in whole or part, as this may cause an unsafe condition.
- Never operate the fixture with missing or damaged lens. Lens must be cleaned on regular basis.
- Entire fixture may become extremely hot. Do not touch hot lens or fixture body.
- Replace LED assembly only with correct wattage and type of power supply appropriate for LED assembly.
- All gaskets, o-rings and sealing surfaces must be kept clean during installation and service; failure to do this may cause an unsafe condition and void product warranty.

IMPORTANT LISTINGS AND CERTIFICATIONS

- Suitable for wet locations

YK - Yukon Direct



IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS


B-K LIGHTING

40429 Brickyard Drive • Madera, CA 93636 • USA
559.438.5800 • FAX 559.438.5900
www.bklighting.com • info@bklighting.com

RELEASE DATE
06/23/2023

REFERENCE NUMBER
INS-2819-00

THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF B-K LIGHTING, INC. AND ITS RECEIPT OR POSSESSION DOES NOT CONVEY ANY RIGHTS TO REPRODUCE, DISCLOSE ITS CONTENTS, OR TO MANUFACTURE, USE OR SELL ANYTHING IT MAY DESCRIBE. REPRODUCTION, DISCLOSURE OR USE WITHOUT SPECIFIC WRITTEN AUTHORIZATION OF B-K LIGHTING, INC. IS STRICTLY FORBIDDEN.




Standard Installation


YUKON

DIRECT - INTEGRAL DRIVER


Phase 1 - Rough in




1. Remove 4 wing nuts and plastic sleeve from housing and save for later use.




2. Knock out one of the knockouts on the back or side of the housing and install conduit.



3. Insert plastic sleeve into housing previously removed on step 1.




4. Drill four 1/4" holes at desired position on concrete form. Please use 1-1 template provided on page 4.




5. Insert all-threads through the four 1/4" holes drilled on the concrete form and install in to the housing. Then hand tighten the 4 wing nuts previously removed in step 1.

Phase 2 - Finish Installation




1. Remove plastic sleeve and all-threads by removing wing nuts.



2. Remove faceplate from fixture by lifting from the bottom up and save for later use.

3. Twist heatsink forward in order to expose screws in the back.



4. Make watertight connections from line voltage to fixture leads using waterproof wire connectors.

⚠ All line voltage connections must be made in compliance with the National Electrical Code. Failure to do so will void warranty.

**IMPORTANT SAFETY INFORMATION LISTED ON REVERSE
READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS**




B-K LIGHTING




40429 Brickyard Drive • Madera, CA 93636 • USA
559.438.5800 • FAX 559.438.5900
www.bklighting.com • info@bklighting.com

RELEASE DATE
06/23/2023

REFERENCE NUMBER
INS-2819-00



Standard Installation




(0-10 Wiring Diagram)

⚠ All line voltage connections must be made in compliance with the National Electrical Code. Failure to do so will void warranty.

5. Once wiring is completed insert fixture into housing.


6. Hand tighten screws using a 5/32" allen wrench.

7. Rotate heatsink/LED assembly back to marked position or desired position.



8. Attach faceplate previously removed on Step 2.

Tamper Resistant Option



1. Tighten two #8-32 stainless steel set screws at the bottom of the faceplate with a 5/64" allen wrench.

**IMPORTANT SAFETY INFORMATION LISTED ON REVERSE
READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS**



B-K LIGHTING

40429 Brickyard Drive • Madera, CA 93636 • USA
559.438.5800 • FAX 559.438.5900
www.bklighting.com • info@bklighting.com

RELEASE DATE
06/23/2023

REFERENCE NUMBER
INS-2819-00